



File Name: Dell Perc H200 Manual.pdf

Size: 4885 KB

Type: PDF, ePub, eBook

Category: Book

Uploaded: 26 May 2019, 23:14 PM

Rating: 4.6/5 from 833 votes.

Status: AVAILABLE

Last checked: 7 Minutes ago!

In order to read or download Dell Perc H200 Manual ebook, you need to create a FREE account.

[**Download Now!**](#)

eBook includes PDF, ePub and Kindle version

[Register a free 1 month Trial Account.](#)

[Download as many books as you like \(Personal use\)](#)

[Cancel the membership at any time if not satisfied.](#)

[Join Over 80000 Happy Readers](#)

Book Descriptions:

We have made it easy for you to find a PDF Ebooks without any digging. And by having access to our ebooks online or by storing it on your computer, you have convenient answers with Dell Perc H200 Manual . To get started finding Dell Perc H200 Manual , you are right to find our website which has a comprehensive collection of manuals listed.

Our library is the biggest of these that have literally hundreds of thousands of different products represented.



Book Descriptions:

Dell Perc H200 Manual

Page Count 92 CAUTION A CAUTION indicates potential damage to hardware or loss of data if instructions are not followed. All rights reserved. Reproduction of these materials in any manner whatsoever without the written permission of Dell Inc. Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own. UCS71, UCS70, and UCSM70 July 2010 Rev. A01 PERC H200.book Page 2 Tuesday, July 13, 2010 4:15 PM WARNING There is a danger of a new battery exploding if it is incorrectly installed. Replace the battery only with the same or equivalent type recommended by the manufacturer. NOTE For complete information on U.S. Terms and Conditions of Sale, Limited Warranties and Returns, Export Regulations, Software License Agreement, Safety, Environmental and Ergonomic Instructions, Regulatory Notices, and Recycling Information, see the Safety, Environmental and Regulatory Information, End User License Agreement, and Warranty and Support Information that shipped with your system. Do not service any product except as explained in your user documentation. Opening or removing covers that are marked with the triangular symbol with a lightning bolt may expose you to electrical shock. Do not attempt to open or service batteries; replace batteries only with batteries designated for the product. PERC H200.book Page 9 Tuesday, July 13, 2010 4:15 PM CAUTION Except as expressly otherwise instructed in Dell documentation, only trained service technicians are authorized to remove the system cover and access any of the components inside the system. CAUTION To help avoid possible damage to the system board, wait 5 seconds after turning off the system before removing a component from the system board or disconnecting a peripheral device. 1 Turn off the system and any connected devices. <http://kitchensofdiablo.com/upload/innova-bensin-manual-vs-matic.xml>

- **dell perc h200 manual, dell perc h200 manual, dell perc h700 manual, dell perc h200 manual pdf, dell perc h200 manual software, dell perc h200 manual downloads, dell perc h200 manual instructions, dell perc h200 manual update, dell perc h200 manual free, dell perc h200 manual system, dell perc h200 manual user, dell perc h700 manual, dell perc h800 manual, dell perc h200 manual.**

2 Disconnect your system and devices from their power sources. To reduce the potential of personal injury or shock, disconnect any telecommunication lines from the system. 3 Ground yourself by touching an unpainted metal surface on the chassis before touching anything inside the system. 4 While you work, periodically touch an unpainted metal surface on the chassis to dissipate any static electricity that might harm internal components. Some cables have a connector with locking tabs. If you are disconnecting this type of cable, press in on the locking tabs before disconnecting the cable. As you pull connectors apart, keep them evenly aligned to avoid bending any connector pins. Hold a card by its edges or by its metal mounting bracket. Hold a component such as a microprocessor chip by its edges, not by its pins. Protecting Against Electrostatic Discharge Electrostatic discharge ESD events can harm electronic components inside your system. Under certain conditions, ESD may build up on your body or an object, such as a peripheral, and then discharge into another object, such as your system. To prevent ESD damage, you must discharge static electricity from your body before you interact with any of your system's internal electronic components, such as a memory module. When connecting a peripheral including handheld digital assistants to your system, you should always ground both yourself and the peripheral before connecting it to the system. The NiMH, lithium coin cell, and lithium ion batteries

are longlife batteries, and it is possible that you will never need to replace them. NOTE Do not dispose of the battery along with household waste. Contact your local waste disposal agency for the address of the nearest battery deposit site. NOTE Your system may also include circuit cards or other components that contain batteries. These batteries too must be disposed of in a battery deposit site. <http://haibeiflavor.com/uploads/file/2020/12/050651449616.xml>

For information about such batteries, see the documentation for the specific card or component. Taiwan Battery Recycling Mark PERC H200.book Page 11 Tuesday, July 13, 2010 4:15 PM The card also enables support for internal tape drives in PowerEdge systems only. The 6Gbps SAS HBA provides support for Dell-supported external SAS tape devices. The PERC H200 and 6Gbps SAS HBA cards are all standard half length, half height PCIe cards, except for the PERC H200 Integrated Modular controller on the blade systems. The PERC H200 and 6Gbps SAS HBA cards are supported with PCIe x8 link width. The cards can be used on platforms with PCIe x8 and x16 connectors, and communicates with SAS devices using 2x4 miniSAS external connectors. The PERC H200 Integrated Modular controller supports PCIe x4 link width only. Data throughput improves because multiple disks can be accessed simultaneously. RAID systems also improve data storage availability and fault tolerance. It provides high data throughput and complete data redundancy. CAUTION Lost data on a RAID 0 disk can not be recovered in the event of a physical disk failure. RAID Terminology RAID 0 RAID 0 allows you to write data across multiple physical disks instead of just one physical disk. RAID 0 involves partitioning each physical disk storage space into 64 KB stripes. These stripes are interleaved in a repeated sequential manner. The part of the stripe on a single physical disk is called a stripe element. For example, in a four disk system using only RAID 0, segment 1 is written to disk 1, segment 2 is written to disk 2, and so on. RAID 0 enhances performance because multiple physical disks are accessed simultaneously, but it does not provide data redundancy. Figure 22 shows an example of RAID 0. PERC H200.book Page 15 Tuesday, July 13, 2010 4:15 PM If one disk fails, the contents of the other disk can be used to run the system and rebuild the failed physical disk.

The primary advantage of RAID 1 is that it provides 100 percent data redundancy. Because the contents of the disk are completely written to a second disk, the system can sustain the failure of one disk. Both disks contain the same data at all times. Either physical disk can act as the operational physical disk. NOTE Mirrored physical disks improve read performance by read load balance. Figure 23. Example of RAID 1 stripe element 1 stripe element 5 stripe element 9 stripe element 2 stripe element 6 stripe element 10 stripe element 3 stripe element 7 stripe element 11 stripe element 4 stripe element 8 stripe element 12 stripe element 1 stripe element 2 stripe element 3 stripe element 1 duplicated stripe element 2 duplicated stripe element 3 duplicated stripe element 4 stripe element 4 duplicated PERC H200.book Page 16 Tuesday, July 13, 2010 4:15 PM Multiple RAID 1 sets are combined to form a single array. Data is striped across all mirrored drives. Since each drive is mirrored in RAID 10, no delay is encountered because no parity calculation is done. This RAID strategy can tolerate the loss of multiple drives as long as two drives of the same mirrored pair do not fail. RAID 10 volumes provide high data throughput and complete data redundancy. Figure 24. Example of RAID 10 stripe element 1 stripe element 3 stripe element 5 stripe element 1 duplicated stripe element 3 duplicated stripe element 5 duplicated stripe element 7 stripe element 7 duplicated stripe element 2 stripe element 4 stripe element 6 stripe element 2 duplicated stripe element 4 duplicated stripe element 6 duplicated stripe element 8 stripe element 8 duplicated PERC H200.book Page 17 Tuesday, July 13, 2010 4:15 PM Dell-compliant SAS and SATA compatibility Yes Dell-supported direct connected end devices Dell-supported external tape devices. Hot add or Hot remove of end devices Yes Support for external tape drive Yes Port activity or status LEDs Yes Hardware-based RAID No Table 32.

<http://www.drupalitalia.org/node/70552>

Specifications of 6Gbps SAS HBA Specification 6Gbps SAS HBA PERC H200.book Page 22 Tuesday, July 13, 2010 4:15 PM The LEDs enable you to quickly determine the status of an external SAS port. Each x4 connector has its own set of LEDs. Green All links in the port are connected and functional. Amber One or more links in the port is not connected. This is only applicable in a wide port configuration. PERC H200.book Page 23 Tuesday, July 13, 2010 4:15 PM NOTE It is recommended that you use a backup power source for all Dell production systems. On a PERC H200 card, caching is forced to be disabled for all physical disks configured into a virtual disk, regardless of the drive type and default drive settings. Unsupported Drives Drives that are not certified by Dell are reported in the BIOS Configuration Utility, also known as. To view unsupported drives 1 In the BIOS Configuration Utility, navigate to the SAS Topology screen. 2 Select the unsupported drive and press to view the Device Properties screen. The drive is marked as Uncertified in the Device Properties screen. Drives that are not certified by Dell are not blocked and you can use them at your own risk. PERC H200.book Page 24 Tuesday, July 13, 2010 4:15 PM You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product. 1 Unpack the PERC H200 card or 6Gbps SAS HBA and check for damage. NOTE Contact Dell if the controller is damaged. 2 Turn off the system and attached peripherals, and disconnect the system from the electrical outlet. See your system's Hardware Owner's Manual or the User's Guide for more information on power supplies. 3 Disconnect the system from the network and remove the cover of the system.

<https://mohacad.com/images/Craftsman-88691-Owners-Manual.pdf>

See your system's Hardware Owner's Manual or the User's Guide for more information on opening the system. 4 Select an appropriate PCIE slot. If replacing a PERC H200 Adapter or 6Gbps SAS HBA, remove the blank filler bracket on the back of the system aligned with the PCIE slot you have selected. NOTE For more information about your system's PCIE slots, see your system's Hardware Owner's Manual. 5 Align the controller to the PCIE slot you have selected. PERC H200.book Page 25 Tuesday, July 13, 2010 4:15 PM See Figure 41. NOTE Figure 41 displays the 6Gbps SAS HBA, but the installation instructions in this section are common for the H200 Integrated, H200 Adapter and 6Gbps SAS HBA. NOTE The H200 Integrated card may have a dedicated PCI slot. For additional details, see the system's Hardware Owners Manual on the Dell Support website at support.dell.com. Figure 41. Installing a 6Gbps SAS HBA 1 bracket screw 2 6Gbps SAS HBA 3 PCIE slot 1 2 3 PERC H200.book Page 26 Tuesday, July 13, 2010 4:15 PM See Figure 42. Figure 42. Connecting the Cable for PERC H200 9 F or the 6Gbps SAS HBA controller, connect the cable from the external enclosure to the adapter. See Figure 43. NOTE The external cable can be connected to either of the two external connectors. 1 SAS x4 internal connector 2 cable 3 PERC H200 Card 3 2 1 PERC H200.book Page 27 Tuesday, July 13, 2010 4:15 PM See your system's Hardware Owner's Manual or the User's Guide for more information on closing the system. 11 Reconnect the power cables and network cables, and then turn on the system. NOTE Ensure that you do not connect a hard disk and tape drive to the same PERC H200 card. To remove the storage controller card 1 Remove the Dell Blade system from the Blade system chassis. 2 Remove the system cover of the Blade system. 3 Remove the system board and place it on a stable and flat surface.

<http://essentialchef.com/images/Craftsman-88733-Manual.pdf>

4 Open the release lever to disconnect the storage controller card edge connector from the system board connector as illustrated in Figure 44. 5 Lift the storage controller card straight up from the system board as illustrated in Figure 44. Figure 44. Removing and Installing the Storage Controller Card 1 storage controller card 2 release lever 1 2 PERC H200.book Page 29 Tuesday, July

13, 2010 4:15 PM NOTE If the card is damaged, contact Dell technical support. 2 Place the storage controller card onto the system board. Align the storage controller card such that the tabs on the system board tray fit through the notches on the edges of the storage controller card. 3 Slide the storage controller card towards the connector on the system board until the storage controller clicks in place. 4 Reinstall the system board. For more information on reinstalling the system board, see your system's Hardware Owner's Manual or the User's Guide. 5 Close the top cover of the Blade system. For more information on closing the top cover of the Modular Blade system, see your system's Hardware Owner's Manual or the User's Guide. 6 Reinstall the Blade system in the Blade system chassis. For more information on reinstalling the Blade system in the Blade system chassis, see your system's Hardware Owner's Manual or the User's Guide. NOTE For the latest list of firmware and installation instructions, see the system documentation located at the Dell Support website at support.dell.com. PERC H200.book Page 30 Tuesday, July 13, 2010 4:15 PM For driver updates, see the Dell Support website at support.dell.com. NOTE Operating system installation on a RAID 1, RAID 0 or a RAID 10 virtual disk is supported only when the virtual disk is in an optimal state. NOTE To ensure you have the latest version of any driver mentioned in this section, check the Dell Support website at support.dell.com. If a newer version exists, you can download the driver to your system. PERC H200.

book Page 31 Tuesday, July 13, 2010 4:15 PM Creating the Driver Media Perform the following steps to create the driver media 1 From the Dell Support website at support.dell.com, browse to the download section for the system. 2 Locate and download the latest PERC H200 or 6Gbps SAS HBA card driver to the system. 3 Follow the instructions on the Dell Support website for extracting the driver to the media. Creating the Device Driver Media Use one of the methods described in the following sections to create the device driver media. Downloading Drivers From the Dell Systems Service and Diagnostic Tools Media 1 Insert the Dell Systems Service and Diagnostics Tools media into a system. The Welcome to Dell Service and Diagnostic Utilities screen is displayed. 2 Select your system model and operating system. 3 Click Continue. PERC H200.book Page 32 Tuesday, July 13, 2010 4:15 PM Select the self-extracting zip file and click Run. Copy the driver to a diskette drive, CD, DVD, or USB drive. Downloading Drivers From the Dell Support Website 1 Go to support.dell.com. 2 Click Drivers and Downloads. 3 Enter the service tag of your system in the Choose by Service Tag field or select your system's model. 4 Select the System Type, Operating System, Driver Language, and Category from the dropdown list. 5 The drivers that are applicable to your selection are displayed. Installing the Driver During a Windows Server 2003 Operating System Installation Perform the following steps to install the driver during operating system installation. 1 Boot the system using the Windows Server 2003 media. 2 When the message Press F6 if you need to install a third party SCSI or RAID driver appears, press the key immediately. Within a few minutes, a screen appears that asks for additional controllers in the system. PERC H200.book Page 33 Tuesday, July 13, 2010 4:15 PM The system prompts for the driver media to be inserted.

NOTE The driver can be provided using a properly formatted USB key. Check the Dell Support website at support.dell.com for additional details. 4 Insert the driver media in the media drive and press. A list of SAS controllers appears. 5 Select the right driver for the installed controller and press to load the driver. NOTE For Windows Server 2003, a message can appear that states that the driver that you provided is older or newer than the existing Windows driver. Press to use the driver that is on the media. 6 Press again to continue the installation process as usual. Insert the installation media and browse to the proper location when prompted. 4 Select the appropriate PERC H200 card from the list, click Next and continue installation as usual. NOTE The Windows Server 2008 R2 operating system includes native support for the PERC H200 card. The driver is automatically installed. For driver updates, see the Dell Support website at support.dell.com. PERC H200.book Page 34 Tuesday, July 13, 2010 4:15 PM The Windows operating system detects the new

controller and displays a message to inform you. 4 The Found New Hardware Wizard screen displays the detected hardware device. 5 Click Next. 6 On the Locate device driver screen, select Search for a suitable driver for my device and click Next. 7 Make the Driver Files available and browse to the proper location from the Locate Driver Files screen. 8 Click Next. 9 The wizard detects and installs the appropriate device drivers for the new RAID controller. 10 Click Finish to complete the installation. 11 Reboot the system if Windows request to do so. NOTE The Windows Server 2008 R2 operating system includes a device driver to support the SAS controllers. The system automatically detects the new controller and installs the driver. Check the version of the driver installed by Windows and update if necessary. PERC H200.book Page 35 Tuesday, July 13, 2010 4:15 PM The Device Manager screen is displayed.

NOTE An alternative method is to open Device Manager. In Windows Explorer, rightclick on My Computer and select Manage. The Computer Management screen is displayed. Select Device Manager in the left panel. 4 Doubleclick on SCSI and RAID Controllers. NOTE In Windows 2008, SAS is listed under Storage Controllers. 5 Doubleclick the RAID controller for which you want to update the driver. 6 Click the Driver tab and click Update Driver. The Upgrade Device Driver Wizard screen is displayed. 7 Make the driver files available with the USB key, or other media. 8 Select Install from a list or specific location. 9 Click Next. PERC H200.book Page 36 Tuesday, July 13, 2010 4:15 PM Installing Linux Driver Use the procedures in this section to install the driver for Linux. The driver is updated frequently. To ensure that you have the current version of the driver, download the updated Linux driver from the Dell Support website at support.dell.com. NOTE The driver update disk DUD images are created only for those operating system releases in which the native inbox driver is insufficient for installation. In the event that an operating system is being installed with a corresponding DUD image, follow the instructions below. NOTE Red Hat Enterprise Linux 5, SUSE Linux Enterprise Server 10 and SUSE Linux Enterprise Server 11 use the mpt2sas driver, whereas Red Hat Enterprise Linux 4 uses the mpt2sasbtm driver. Examples in this section refer to the mpt2sas driver only. For Red Hat Enterprise Linux 4, replace mpt2sas with mpt2sasbtm. Creating a DUD Before beginning the installation, copy the drivers from the Service and Diagnostic Utilities media or download the appropriate driver for Linux from the Dell Support website at support.dell.com. This file includes Red Hat Package Managers RPMs and driver update disk files. The package also contains the Dynamic Kernel Module Support DKMS Red Hat Package Manager RPM file, source code, and release notes.

For more information on DKMS, see the Dell Support website at support.dell.com. PERC H200.book Page 37 Tuesday, July 13, 2010 4:15 PM After downloading the package to a Linux system, perform the following steps 1 Unzip the package using gunzip. 2 Untar the file using tar xvf. Use the appropriate image for the purpose. Use the appropriate image for the purpose. Use dmesg to find out to which device this USB floppy is enumerated for example, sdb, sdc, etc. NOTE The driver must be installed on the system where this procedure is performed. 1 Install the DKMSenabled mpt2sas driver rpm package. 2 Type the following command in any directory `dkms mkdriverdisk mpt2sas v k d` NOTE The values for the d option are suse for Suse Linux Enterprise Server diskettes and redhat for RHEL diskettes. NOTE For more information on usage of DKMS, see the DKMS man page. This starts the process to create the mpt2sas DUD image. After the DUD image has been built, you can find it in the DKMS tree for the mpt2sas driver. See the output of the `dkms mkdriverdisk` command for the exact path. For SLES 11, select. The system displays three options Yes, No, and File. Choose Yes to install the driver. 3 Select Installation from the menu. 4 Press to load the Linux kernel. 5 At the prompt Please insert the driver update floppy, click OK. The system selects the driver from the diskette and installs it. The system displays the message DRIVER UPDATE ADDED with the description of the driver module. 6 Click OK. If you want to install from another driver update medium, continue with the following steps. 7 The system displays the message PLEASE CHOOSE DRIVER UPDATE MEDIUM. 8 Select the appropriate driver update medium. The system

selects the driver from the disk and installs it. PERC H200.book Page 40 Tuesday, July 13, 2010 4:15 PM Upgrading the Kernel When upgrading to a new kernel, you must reinstall the DKMS-enabled driver packages. You must press any key to continue.

The BIOS Configuration Utility allows you to choose to continue booting or stop booting if errors are encountered. PERC H200.book Page 43 Tuesday, July 13, 2010 4:15 PM If you add a PERC H200 or 6 Gbps SAS HBA card or relocate existing controllers in the system, enter the BIOS Configuration Utility to update and verify the boot order selection. Failure to do so results in a warning message displayed at POST by the BIOS. The warning persists until you verify the boot order in the BIOS Configuration Utility. NOTE System boot is not supported from an external device attached to a 6Gbps SAS HBA card. See the Dell Support website at support.dell.com for the latest information on booting from external devices. Configuration Utility Starting the Configuration Utility 1 Boot the system. 2 Press during POST when prompted. If you wait too long and the operating system logo appears, continue to wait until the operating system completes bootup. Then restart your system and try again. The Configuration Utility menu screen is displayed. Functions Performed NOTE The screens are organized in a hierarchical fashion and navigation hints are displayed at the bottom of each screen. For additional information about the utility, see the online help. PERC H200.book Page 44 Tuesday, July 13, 2010 4:15 PM Global Properties Lists static and modifiable properties applicable to all PERC H200 and 6Gbps SAS HBA cards in the system. Adapter Properties Main screen for the selected controller. Lists the static and modifiable properties for the selected PERC H200 and 6Gbps SAS HBA cards. Provides a menu for additional screens. Select New Volume Type Provides the option to view existing arrays or create new volumes. Create New Volume Provides the ability to add devices to the specified new volume. View Volume Displays the properties for the existing volume and the option to enter the Manage Volume screen.

Manage Volume Provides options for managing the current volume. Manage Hot Spares Provides the ability to add or remove global hot spares. SAS Topology Lists the physical topology for the selected controller. Device Properties Lists the properties of physical devices attached to the selected controller. Advanced Adapter Properties Lists the advanced properties for the selected controller. PERC H200.book Page 45 Tuesday, July 13, 2010 4:15 PM Online help is also available in the utility. NOTE After you press, press on the adapter to manage it. RAID Configuration and Management Screens RAID configuration and management involves many GUIs. You can access the GUIs by selecting RAID Properties on the Adapter Properties screen. Select View Existing volume to manage the volumes, or select the appropriate option to configure a new volume, if at least one RAID volume is currently configured. Verify Provides the ability to verify all sectors on the device and to reassign defective Logical Block addresses LBAs. Consistency Check Provides the ability to run a consistency check on an optimal volume. Delete Provides the ability to delete the selected volume. Activate Volume Provides the ability to import a foreign volume. Table 61. Functions of the Configuration Utility continued Function Description PERC H200.book Page 46 Tuesday, July 13, 2010 4:15 PM After the volume is created, the utility returns to the Adapter Properties screen. See the table below for the volume properties description. NOTE It is recommended that you back up your data prior to adding or updating configurations. Table 62.

Volume Field Descriptions Field Description Volume Number Number of current volume out of total arrays configured Volume Identifier Identifier text for the current volume Volume Type Type of volume R0, R1 or R10 Volume Size GB Size of the volume NOTE To facilitate coercion on new larger disk drives, the disk size must be coerced down with a factor of 128 MB. Additionally, to comply with the latest Disk Data Format standard, 512 MB of space must be reserved for RAID metadata on the drive. This results in several hundred MB of space being removed from the usable size of an volume when it is created. PERC H200.book Page 47 Tuesday, July 13, 2010 4:15 PM

Degraded —One or more members of a RAID 1 or RAID 10 volume have failed or are offline. The volume can be returned to the Optimal state by replacing the failed or offline member. Disabled —The volume is disabled Quiesced —The volume is quiesced Resync —The volume is resynchronizing Failed —The volume has failed PermDegraded —The volume is permanently degraded. This state indicates that the failure threshold on the primary member was reached while no secondary was available for correction. The data on the volume may be accessible, but the volume cannot be returned to the optimal state. Inactive —The imported volume is inactive. The volume must be activated before it can be accessed. Initializing —The array is undergoing Background Initialization BGI Pending —The array is queued up for a Background Initialization Checking —The array is queued up for a Consistency Check Slot Number Slot number in which the specified device sits Device Identifier Identifier text for the specified device RAID Disk Specifies whether or not the disk is part of a RAID volume Yes or No.Missing Disk is not detected. Failed Disk is not accessible or has reported a failure. Initing Disk is initializing. CfgOffln Disk is offline at hosts request. UserFail Disk is marked failed at hosts request.

Offline Disk is offline for some other reason. Inactive Disk has been set to inactive. Not Syncd Data on disk is not synchronized with the rest of the volume. Primary Disk is the primary disk for a 2 disk mirror and is OK. Secondary Disk is the secondary disk for a 2 disk mirror and is OK. Wrg T y p e Device is not compatible for use as part of a RAID volume. Too Small Disk is too small to mirror existing data. No SMART Disk doesnt support SMART and cant be used in a RAID volume. Predicted Failure Indicates whether device SMART is predicting device failure. Size GB Actual physical size of the selected disk in the volume. NOTE The PERC H200 cards do support Drive Status LED operation on PowerEdge systems which include drive status LEDs. Status LED support is only supported for drives which are configured as members of a Virtual Disk or Hot Spare. PERC H200 supported Drive Status LED states may vary from those supported by other hardware based RAID solutions such as the PERC H700 and H800 controllers. NOTE Replacing a member of a volume in the Permanently Degraded state will result in the new physical disk being displayed as failed since resynchronization is not possible. This does not indicate an actual failure on the new physical disk.

Table 62. Volume Field Descriptions continued Field Description PERC H200.book Page 49
 Tuesday, July 13, 2010 4:15 PM Press to view the next volume. See Table 62 to view descriptions of each virtual disk property. Manage Volume The Manage Volume screen is used to manage the current volume. The options are Manage Hotspares, Consistency Check, Activate Volume, and Delete Volume. Table 63. Manage Volume Field Descriptions Field Description Identifier The identifier of the volume Type The RAID type of the volume Size GB The coerced size of the volume NOTE To facilitate coercion on new larger disk drives, the disk size must be coerced down with a factor of 128 MB.

<http://www.drupalitalia.org/node/70554>