


Dri Steem Installation Manual



File Name: Dri Steem Installation Manual.pdf

Size: 3072 KB

Type: PDF, ePub, eBook

Category: Book

Uploaded: 12 May 2019, 15:31 PM

Rating: 4.6/5 from 698 votes.

Status: AVAILABLE

Last checked: 2 Minutes ago!

In order to read or download Dri Steem Installation Manual ebook, you need to create a FREE account.

[Download Now!](#)

eBook includes PDF, ePub and Kindle version

[Register a free 1 month Trial Account.](#)

[Download as many books as you like \(Personal use\)](#)

[Cancel the membership at any time if not satisfied.](#)

[Join Over 80000 Happy Readers](#)

Book Descriptions:

We have made it easy for you to find a PDF Ebooks without any digging. And by having access to our ebooks online or by storing it on your computer, you have convenient answers with Dri Steem Installation Manual . To get started finding Dri Steem Installation Manual , you are right to find our website which has a comprehensive collection of manuals listed.

Our library is the biggest of these that have literally hundreds of thousands of different products represented.



Book Descriptions:

Dri Steem Installation Manual

Get in touch. These humidifiers are the best choice for customers with available natural gas or propane who require reliable steam humidification at the lowest operating cost for any application from comfort to critical. Observing the installation and operating practices described in this manual will assure you of achieving that objective. We urge you to become familiar with the contents of this Humidifier Company Single Tube Humidifier Field 3 Installation. Observing the installation and operating practices described in this manual will assure you of achieving that objective. Where an airtight seal is required, use a suitable caulk around duct. Install steam strainer and steam trap. Connect to steam and condensate return mains. See page 5 for piping. Install control tubing pneumatic or wiring electric to valve actuator. Note An airflow proving device should be installed to prevent valve from opening unless air is moving in. High limit duct mounted humidistat installed downstream and set at 80-90% is recommended when duct air is below 70 F to prevent condensation in duct. 4 This device should be mounted far enough downstream to assure injected steam has been completely absorbed. 6. A temperature switch to prevent possible cold start dripping is recommended when steam pressure to the humidifier is cycled. See page 11 for Silencers are furnished only with model 560 and 670 humidifiers having tubes equal to and shorter than 4 feet all others do not have silencers unless specially ordered. Actuator Strainer Steam discharge inserts Steam trap Field Assembly Small units are shipped assembled; the following apply to larger units that are disassembled for Unpack shipment and verify receipt of all components with packing list. 5 Report any shortages at Match up dispersion tube with its proper valve separator assembly tubes and separators are match tagged. <http://www.seikan.cz/userfiles/cpanel-backup-manually-run.xml>

- **dri steem installation manual, dri steem gts installation manual, dri steem vapormist installation manual, dri steem installation manual.**

Tubelets should point toward the airstream for better steam air mixing, except if tubes have fiberglass insulated jacket option steam could condense on cool jacket in which case they should discharge with the Unscrew pipe union, remove elbow and nipple portion, and install in half nipple of tube. Note Before completing step 3, determine which way right or left steam holes should point and install in appropriate half. Install tube adapter in valve, use pipe dope and tighten leak tight. Orings are installed inside of tube Lubricate Orings before Insert tube adaptor into dispersion tube. 6 As this is being done, squeeze hooks of silencer cage together see note below, and slide them into the tube adapter, allowing them to snap over rear edge of adapter. Complete inserting adaptor into tube, being careful not to damage Bring union halves together, tighten union ring, and snug up TEFLON seal ring not too tight. Insulated tubes should discharge with the airflow to prevent condensation on the metal jacket covering the insulation. 8 A minimum duct velocity of 300 FPM with insulated dispersion tubes is 41 Right hand configuration Horizontal tube and horizontal steam discharge. This arrangement comprises the majority of uses. Unless ordered otherwise, this is how units are shipped. Unit shown above is righthanded. To change from right to left, see the bottom of this when there is no access to side of duct. Humidifier steam supply should be taken off the top of the steam main not the side or bottom to ensure driest steam. Main should be dripped and trapped in accordance with ASHRAE recommendations. 10 2. Humidifier steam trap must drain by gravity to the return main having little or no back pressure. Unpack shipment and verify receipt of all components with packing list. Report any shortages at Plan the tube bank. Show more Excessively high or low humidity causes Releasing steam to the atmosphere with such energy gives a lot of mist formation and noise. A adaptor Boa rd. Installation

Manual. <http://www.teleinwestor.pl/userfiles/cpan-moose-manual.xml>

Warnings and cautions. This page provides important safety instructions; it is intended to supplement—not replace—the humidifiers Installation, Operation, and Maintenance Manual IOM. Read the IOM that was provided with the humidifier before performing service or maintenance. Failure to follow all warnings and instructions could produce the hazardous conditions. If the IOM is missing, go to [to download a replacement](#). Hot surfaces and hot water. Steam humidification systems have extremely hot surfaces, and water in tanks, electrode cylinders, steam pipes, and dispersion. To avoid severe burns, allow the entire humidification system to cool. Follow the cooldown procedure in the humidifiers IOM before performing service or maintenance procedures on any part of the humidification system. Shut down the energy source. Before performing service or maintenance procedures on any part of the humidification system, verify that all energy sources are shut down. Failure to shut down the energy source could result in carbon monoxide or other hazardous conditions. Contact with energized circuits can cause property damage, severe personal injury or death as a result of electrical shock or fire. Follow the shutdown procedure in the humidifiers IOM before performing service or maintenance procedures on any part of the humidification system. **Tools required.** Before beginning the upgrade..... 2. GTS humidifiers. Board removal and replacement. Removing Vaporlogic3, installing Vaporlogic4. Transferring expansion board terminal blocks. Safety circuit wiring. Leave safety circuit wired in series with one alarm. Separate safety circuit alarm signals into three alarms..... Board removal and replacement. Removing Vaporlogic3, installing Vaporlogic4..... 10. Transferring expansion board terminal blocks..... 12. STS humidifiers. Board removal and replacement..... 16. All Humidifiers. Startup and validation.

Vaporlogic4 adaptor board pin descriptions..... Back cover. Before beginning the upgrade. Before disconnecting power. Installation and Operation manual for Parts. Make sure all parts listed below are included in the Vaporlogic3 to Vaporlogic4 upgrade kit you received. Table 21. Vaporlogic3 VL3 to Vaporlogic4 VL4 adaptor board kits. Part No. 183503001. No. Description. Qty. Terminal blocks connect to pin locations with Figure 21. Matching pin numbers on board and Part No. 183503002. No. Qty. Board removal and replacement. Removing Vaporlogic3, installing Vaporlogic4. Figure 31. Before performing any maintenance or repair, unscrew standoffs, and remove board and standoffs they will not be used. Figure 31. GTS subpanel. Figure 32. VL4 adaptor board standoffs. Top wire channel Standoff. Bottom of VL4 adaptor board shown. Vaporlogic4 adaptor board see Figure 41. If present, plug laptop. Figure 42. Determining LonTalk interoperability. VL3 board LonTalk connections. If upgrading to Vaporlogic4 with LonTalk interoperability, disconnect wires from Vaporlogic3. LonTalk pins and land them as instructed in Table 41. Table 41. Landing LonTalk wires. Disconnect wire from this. Connect it to this pin on Vaporlogic4. Vaporlogic3 board LonTalk pin adaptor board LON ProtoCessor Module. Corner of VL3 main board shown. Ground. Ground pin P12, P24, P43, P63, or P193. Vaporlogic boards. VL4 adaptor board two stacked boards; top board shown. LON ProtoCessor Module. Board removal and replacement. Remove adhesive. Figure 51. Splitting interlocked terminal blocks. Notes. Some 4pin terminal blocks are two interlocked 2pin. See Figure 51. Scrape away any pin hole or screw corrosion before landing. Not all Vaporlogic3 wire connections will be used for this. Strip ends of Figure 52. Jumpering terminals T2 and 33. Top edge of VL4. Transferring expansion board terminal blocks.

<http://dev.pb-adcon.de/node/19575>

Leave the wires in the terminals when transferring the terminal blocks. Note To facilitate wire rerouting and provide slack, remove top wire. GTS humidifiers have one or two Vaporlogic3 expansion boards. If upgrading from Vaporlogic3 with two expansion boards, land Vaporlogic4 adaptor board pin locations for Vaporlogic3 expansion boards. GTS humidifiers. Figure 61. Indoor GTS with outdoor enclosure. Remove end screws. Screws will be reused. GTS humidifiers. Figure 71. Remove fan and

bracketGTS04PNLASM50view. Figure 72Mounting screws useGTS humidifiers. Leave safety circuit wired in series withP33 and P34 on Vaporlogic4 adaptorP33 on Vaporlogic4 adaptor board. IfTorque terminal. Proceed to "Startup and validation" on. Page 19. Figure 81. Leaving safety circuit wired in seriesVL3 expansion boardWhether leaving alarm signals in series or separating them, you mustNote If needed, refer to the Vaporlogic3 wiring diagram and the. Vaporlogic4 Installation and Operation Manual for moreSeparate safety circuit alarm signals into three alarmsDoor interlock switch Figure 91Remove other end of wire from position 11 on low water relay, andRemove fork connector endBlocked flue switch Figure 91Run wire to P34Cut wire to length,Low water circuit Figure 91Land other end at terminal. P33 on Vaporlogic4 adaptor board. The following steps are for GTS without door interlock switch. Figure 92. Separating safety circuit alarm signalsBlocked flue switch Figure 92. VL3 withoutVL3doorMain boardLand wire at one of the h terminals 24 Vac on terminal strip atRemove other end of this wire from position 11 on low waterLand other end of this wire at terminal P33 at top of Vaporlogic4FPswSeparating safety circuit alarm signals GTS with door interlock switch. VL3 with doorVL3VL4 adaptorVL4 adaptorMain boardLow water relayExpansion boardBlocked flue switch 415ABoard removal and replacement. Removing Vaporlogic3, installing Vaporlogic4Shut down humidifier.

Before performing any maintenance orRemove galvanized subpanelRibbon cables will not be reused.Figure 101Unscrew standoffs, and remove board and standoffs they will notIf present,VL4 adaptor board standoffs. StandoffIf upgrading to Vaporlogic4LonTalk pins and land them as instructed in Table 101. Table 101. Ground pin P12, P24, P43, P63, or P193Electric humidifiers. Figure 111. Vaporlogic boards. VL4 adaptor board two stacked boards; top board shown. The Vaporlogic4 adapter board pin descriptionsDetermining LonTalk interoperability. VL3 board LonTalk connections if no wires, then no LonTalk. Electric humidifiers. Board removal and replacementRemove adhesiveFigure 121. Splitting interlocked terminal blocksNotes Some 4pin terminal blocks are two interlocked 2pinSee Figure 121. Scrape away any pin hole or screw corrosion before landingNot all Vaporlogic3 wire connections will be used for thisFigure 122. Jumpering terminals T2 and 33Top edge of VL4Strip ends ofVaporlogic4 adapter board. Transferring expansion board terminal blocksSome Vaporstream humidifiers have a Vaporlogic3 expansion board. Vaporlogic4 adaptor board pin locations for Vaporlogic3 expansionFigure 111. Leave the wires in the terminals when transferring the terminal blocksNote To facilitate wire rerouting and provide slack, unbundle wiresElectric humidifiersVapormist and HumiditechElectric humidifiers. The following procedure leaves the safety circuit door interlock andFigure 141.Proceed to "Startup and validation" on Page 19. Figure 141. Leaving safety circuit wired in series with one alarm. VL3 main board. Grayhandled jumper provided withGrayhandled jumper provided withVL4 adaptor boardSafety circuit wiring. Figure 151. Leaving safety circuit wired in seriesThe following procedure leaves the safety circuit door interlock andVL3 expansion board Vaporstream onlyVaporlogic4 adaptor board. If wire 801 does not reach P33, useTorque terminal block screws to. Proceed to "Startup and validation" on Page 19.

VL3 main board. VL3 expansion board Vaporstream onlyVL4 adaptor boardBoard removal and replacementBefore performing any maintenance orFigure 161. StandoffUnscrew standoffs, and remove board and standoffs they will notIf present,Bottom of VL4 adaptor board shown. Figure 162. VL3 board LonTalk connectionsIf upgrading to Vaporlogic4LonTalk pins and land them as instructed in Table 161.Remove adhesiveNotes Some 4pin terminal blocks are two interlocked 2pinSee Figure 163. Scrape away any pin hole or screw corrosion before landingCorner of VL3 main board shown. Figure 163. Splitting interlocked terminal blocks. Not all Vaporlogic3 wire connections will be used for thisTable 161. Ground pin P12, P24, P43, P63, or P193Board removal and replacementT2 and 33 on Vaporlogic4 adaptor board Figure 172. StripFigure 172. Jumpering terminals T2 and 33Top edge of VL4JumperFigure 171. The Vaporlogic4 adapter board pin descriptionsLON ProtoCessor

Module Figure 181. Leaving safety circuit wired in series VL4 adaptor board Proceed to "Startup and validation" on Page 19. Startup and validation. Startup. See the Startup commissioning checklist in the humidifier's. Installation, Operation, and Maintenance Manual. Before resuming Refer to the Vaporlogic4. Installation and Operation Manual, and validate every parameter in the. Vaporlogic4 Setup menu. Figure 191. Field conversion label. When the upgrade is complete, fill out the Field Conversion Label included with the upgrade kit, and When resuming operation, do not leave the humidifier unattended; Test outputs. When completing an installation or repair, cycle all outputs, such as Go to the test outputs During testing, the humidifier mode Test run. Vaporlogic4 has a test run capability to confirm system functionality. This capability allows a technician to simulate a demand for steam Set system demand percent and set test run time Humidifier Descaling Solution.

Scale buildup on humidifier heaters and heat DRISTEEMs Humidifier Descaling Solution, The Descaling Solution cleans without risk Descaling Solution also cleans surfaces DRISTEEMs Humidifier Descaling Solution Use of other Va p o r l o g i c 4 a d a p t o r b o a r d For more information For the most recent production information Table 201. Vaporlogic4 adaptor board pin descriptions STS Page 18 An ISO 90012000 certified company. U.S. Headquarters Eden Prairie, MN 55344 European office. Marc Briers. Grote Hellekensstraat 54 b. B3520 Zonhoven. Belgium. Function. Safety circuit Tank temp sensor input Continuous product improvement is a policy of. DRISTEEM Corporation; therefore, product features and DRISTEEM, GTS, Vaporlogic, Vapormist, and Vaporstream, European community. Dranekooler is a trademark of DRISTEEM Corporation. Product and corporate names used in this document may They are used for DRISTEEM products are warranted according to the terms and conditions of the standard See the literature Form No. VL3VL4 Convert 0511. Part. No. 890000720 Rev D. Installation, Operation Weights, connections and heated water properties..... Clearance recommendations..... 9. Mounting. Piping. Alternative water seal and drain valve..... 25. Dispersion. Interconnecting piping requirements..... 32. Single and Multiple dispersion tubes..... 35. Operation. LW417 automatic drain and flush. LW417 variable skim times. LW417 end of season drain. LW417 Onboard diagnostics..... Troubleshooting Replacement parts. Overview Figure 31. LTS standard water model. Standard water LTS humidifiers heat Steam outlet. Modulating Heat Hot liquid Manual drain or optional Deionized water models LTSDI. LTSDI humidifiers heat deionized DI or Air gap. Hot liquid Water seal. Open drain Figure 32. Steam outlet. Modulating Float valve. Heat exchanger. Hot liquid LTSDI models can be converted in the Manual drain valve. Air gap. Hot liquid supply. Water seal.

Open drain Dimensions, LTS models 25C and 100C one heat exchanger. Front view. Side view LTS dimensions. LTS model number. Description Overview Dimensions, LTS models 400C two heat exchangers. LTS model. Description LTS output capacities using hot water. Flow Hot water supply temperature The LTS is not ASME certified. Overview LTS connection sizes. Connection size. Water makeup ll. Drain. Varies with capacity and dispersion type. Condensate return. Hot liquid supply inlet and return outlet. See dimensions tables. Table 72. LTS weights. LTS model Operating weight. Table 73. Temperature When selecting a location for the humidifier, consider the following Installation. Figure 91. LTS clearance recommendations. For recommended service and maintenance purposes, maintain the following clearances. Left side with control Left side Top. Rear. Angle iron Front. Right Bottom Table 101. Mounting options by model. To ensure that the water level control system works properly, the Mounting Trapeze. Optional Optional Support legs, trapeze hanger, and wall brackets are not available for. These models must use Hlegs. The mounting methods described in this manual are the only ETL, and CETL approvals. Installation Overhead installation. Do not install water piping and humidifiers A broken water pipe, leaking valve gland, Secure threaded rod to an overhead structure that is strong enough Adjust the mounting so that the tank sets level side to side and If this type of installation cannot be Pipe the overflow from the LTS directly to Figure 111. Trapeze hanger LTS models 25C and 100C only. Secure rods to overhead construction Angle or

channel sized to Humidifier drain to appropriate. Install water seal as shown on. Pages 24 and 25. Drip pan recommended. Figure 121. Support legs. Use enclosed bolts, nuts, and washers to fasten legs to tank. Shim legs. Optional set of legs required for LTS models 400C. While the LTS and LTSDI tank is securely held in the air, then tighten them after the unit is in place.

Adjust the mounting so the tank sets level side to side and front to back. Installation of LTSDI tank. LTSDI tank, and fasten to the horizontal timbers. Figure 131. Wall brackets for LTS model. Run a bolt with a washer through the face of LTS Outdoor Enclosure with standard or optional steam outlet, elevation view. Standard steam outlet. Optional steam outlet. LTS humidifier. See Note 2 below. Pipe chase. The standard configuration has a steam outlet on the optional internal steam distribution. Run the electrical power into the enclosure at these knockouts. Depending on the application, interconnecting piping from the tank. If one of these valves must be located inside the enclosure, see Figure 151. LTS Outdoor Enclosure, top view. Valve access door. Intake ventilation fan. Enclosure drain. Control panel. Control panel heater. Standard steam outlet exits enclosure here. LTS humidifier. Electrical and cleanout access door. Intake ventilation fan. LTS or LTSDI. Item. Description. Note. Specifications. Note. Table 161. LTS Outdoor Enclosure weights. LTS or LTSDI. Outdoor Enclosure. The Outdoor Enclosure is only available in Table 162. LTS Outdoor Enclosure connection sizes. LTS or LTSDI model number. Condensate return. Steam outlet. Figure 171. Outdoor enclosure installation detail. Normally closed. Makeup water supply piping. Disconnect by installer; see Detail A. Humidifier. Open to drain. Vent with check valve. Roof decking. Detail A. Optional water seal. P-trap drain. Normally closed. Disconnect. Domestic water, 80 psig. Open drain. Heated building interior. Open drain. To valves by Note 1. To LTS humidifier. To ensure that water does not remain in the fill line and freeze if there is a power outage. On a loss of power the tank water will drain, but not be cooled. If it is critical to keep the DraneKooler functional in the case of a power outage, the supply water for the DraneKooler before the safety shutoff valves. Refer to governing code. Figure 181. Outdoor Enclosure mounting options.

Outdoor Enclosure mounting. Flush. The use and storage. Locate the Outdoor Enclosure so that all nuts are tightened. It is the installer's responsibility. All lifting operations must be accomplished with a load spreader. All four lifting points must be used and will be marked "lift here". The optional internal steam distribution. See drawings on. Page 15. Important note about Outdoor Enclosure installation. Enclosure. If one of these valves must be located inside the enclosure, see Figure 191. Outdoor Enclosure clearances. Left side. Top. Keep open. Back. Right side. TUBOEBSEHNCurbs are manufactured of 16 gauge. The gasket must be installed between the top of the curb and the enclosure to prevent the outdoor environment from being affected. Note. If your LTS humidifier uses a LW417 enclosure is recommended. Insulated or heat taping of water piping. Figure 201. Typical rooftop installation overview. Flue. Humidifier in Outdoor Enclosure. Roof surface. Electrical. Remote. Steam piping. Curb. Drain piping. Water piping. When power is applied to the Outdoor Enclosure, the strip heaters will power down when the temperature inside the enclosure reaches a set point. Always shut off electrical service to the enclosure before working on it. Field piping overview for LTS models 25C and 100C models with one heat exchanger. Shock arrester recommended. Water supply shutoff valve, by installer. Steam vapor outlet. Install level. Water supply line; water pressure range 25 psi to 80 psi. Unions, by installer. Optional condensate return. Air vent. Install level. Modulating valve. H2 Air vent height. Ho. Ho. Manual or electric drain valve. Overhead air vent height. If run is over 10.3 m, H1 Pitch. Water seal line. MUST be below open or drain. Refer to governing codes. Heights required to overcome unit output. Water seal. Air vent. If variable system flow is desired, a two-way valve located in the hot liquid return line is recommended. DRISTEEM warranty. Installation. Field piping overview for LTSDI 400C DI model with two heat exchangers. Water supply line; water pressure range 25 psi to 80 psi (172 kPa). Optional condensate return. Strainer, by installer. Modulating. Ho. Air vent tube. Install level. Manual or electric drain valve. Overhead air vent height. See valve unions, by installer. If run is over 10.3 m, Water seal line.

MUST be below open or drain. Refer to governing codes. If variable system flow is desired, a two-way valve located in the hot liquid return line is recommended. DRISTEEM warranty. Threeway valve detail. Ho return. From drain to drain. Ho up. When the threeway valve is retracted in the up position, the DraneKooler water tempering

device. The drain line piped from the humidifier must be run to an If nonmetallic pipe This steam will rise and saturate electrical components, adversely DRISTEEMs Dranekooler, shown mounted OM951a The Dranekooler option will Drain piping after the water seal must be pitched a minimum of Installation LTS humidifier UIFESBJODPOOFDUJPOUPBO54TUBOEBSEXBUFSThe LTSDI humidifier has a pipe thread fitting on the drain valve Prior to dumping into a drain, the Alternate water seal and drain valve piping. Typically, the water seal height dictates the minimum dimension The alternate Alternate water seal and drain valve piping. Skimmer outlet. Top of water seal must be H1 see table on Page 22. Drain Air gap.

<http://www.familyreunionapp.com/family/events/dynatron-850-manual>