



**OPERATING INSTRUCTIONS**

- 6) Place fountain in desired location. If placing on carpet, tile or wood flooring use a protective surface such as a towel or place mat to protect your floor from splashing or dripping from your pet.
- 7) Fill the fountain with water. This includes the bowl and the housing. This will prime the pump. Replace the lid and snap into place.
- 8) Remove the reservoir by lifting up and away from the fountain. Turn the reservoir upside down and remove the the reservoir cap. Fill the reservoir with water and replace the cap. Holding the reservoir upside down and backwards to the fountain (Fig. 1d), quickly turn the reservoir right side up and slide into place (Fig. 1e). The water level will equalize to approximately 1.27 cm below the rim of the bowl.



- 9) Before you plug in the fountain make sure the cord and your hands are dry. Plug the fountain in.
- 10) Set your desired flow rate with the flow control knob, located to the right of the splash ramp. In the 10 o'clock position for a smaller stream or in the 2 o'clock position for a strong stream. (Fig. 1f)




Fig. 1f

- 11) Add water as needed. Do not let the water level fall lower than the flow control knob or you may burn out the motor. Do not pick up a full fountain by the filter housing. Only use the handles located on the bottom of the bowl on either side of the fountain.

**6** [www.petsafe.net](http://www.petsafe.net)

**File Name:** Drinkwell Instruction Manual.pdf

**Size:** 1247 KB

**Type:** PDF, ePub, eBook

**Category:** Book

**Uploaded:** 26 May 2019, 13:33 PM

**Rating:** 4.6/5 from 786 votes.

**Status:** AVAILABLE

Last checked: 9 Minutes ago!

**In order to read or download Drinkwell Instruction Manual ebook, you need to create a FREE account.**

[\*\*Download Now!\*\*](#)

eBook includes PDF, ePub and Kindle version

[Register a free 1 month Trial Account.](#)

[Download as many books as you like \(Personal use\)](#)

[Cancel the membership at any time if not satisfied.](#)

[Join Over 80000 Happy Readers](#)

## Book Descriptions:

We have made it easy for you to find a PDF Ebooks without any digging. And by having access to our ebooks online or by storing it on your computer, you have convenient answers with Drinkwell Instruction Manual . To get started finding Drinkwell Instruction Manual , you are right to find our website which has a comprehensive collection of manuals listed.

Our library is the biggest of these that have literally hundreds of thousands of different products represented.



## Book Descriptions:

# Drinkwell Instruction Manual

Washing your filter will allow the soap to seep into the pores and this cannot be removed, making the filter unusable and unsafe for your pet. The filter removes bad tastes and odours to improve the taste of the water and catches hair and small particles to keep the water cleaner. Either wash it in the top rack of your dishwasher or handwash these parts. If your dishwasher runs too hot, we recommend handwashing. When handwashing, use a bottle brush, aquarium brush, soft sponge, or brushes included in the Fountain Cleaning Kit and dish soap. Please note if you have the Avalon or Pagoda fountains, the filter housing should be hand washed. It is not dishwasher safe. There may be a faceplate cover over the impeller than can be pulled up with a coin or fingernail. Wash the impeller in soapy water, removing hair and other gunk that has collected around it. A cotton swab or small toothbrush might work too, or anything that can reach all the way inside of the cavity. Fill with water. Replug in fountain. This is a new object added to their environment, so give your pet enough time to get used to the fountain at their own pace. This time frame will usually only take a few days, and it is very rare that a pet will refuse to use the product entirely. If your pet prefers to drink running water from the faucet or shower, your pet will probably get used to the fountain very quickly. This way your pet can get used to drinking from the fountain without the noise and splash of running water. Try setting it to a lower flow setting. Remove the filter from the fountain, then add tuna juice or bouillon to the water until your pet is used to the new product. After that, you can clean the fountain, replace the filter, and refill the fountain with regular water. The filters do not purify the water. Change them every 24 weeks, depending on how many pets use the fountain, to keep the fountain water fresh and clean.<http://soyuzmedexpert.ru/userfiles/cracked-by-service-manual-aoreteam.xml>

- **drinkwell instruction manual, drinkwell platinum instruction manual, drinkwell pet fountain instruction manual, drinkwell pet fountain instruction manual, drinkwell platinum instruction manual, drinkwell 360 instruction manual.**

If you have more pets or notice more debris, a slimy feel, or decreased water flow in your fountain, you should clean it more often. Prefilters can usually be changed less frequently. Change the water and clean your fountain more frequently to prevent this. Soap residue may cause the sliminess. Be sure to rinse every part thoroughly before reassembling the fountain. To remove these deposits, clean the fountain parts with a 90% water, 10% vinegar solution. Rinse all parts thoroughly afterwards. Use filtered or purified water instead of hard tap water to prevent this. Some pets are prone to spilling. Watch your pet when he drinks to see if this is the cause. If it is, you can purchase a fountain mat or other waterresistant mat to place under the fountain. Look for visible cracks in the bowl. Some fountains hum a little louder than others. It should return to normal levels within a few minutes. If the noise stops when plugged back in, its possible that some debris is caught on the impeller. Remove the pump and clean the impeller. Try rubbing a small amount of vegetable oil onto the magnetic pin with a cotton bud to lubricate the impeller. See below for full cleaning steps. Try adding plain white vinegar inside the pumps cavity without the impeller and allow it to soak for 1015 minutes. Allow the impeller to soak in a separate bowl of vinegar for the same duration of time. Clean all fountain parts in soap and water before reassembling the fountain. Gently but firmly press down on this pin to reseal it into its proper place in the motor. If the pin has completely dislodged itself from the motor, it cannot be placed back into the motor cavity properly and the motor will have to be replaced. Call Customer Care for information on replacing your motor. Sometimes it takes a few minutes for the motor to start pumping water once its refilled or plugged

in. <http://formula-rentacar.com/userfiles/craden-dp9-manual.xml>

If water doesn't flow after 5 minutes, try these troubleshooting tips. To prevent this, you can purchase a cord cover from most hardware stores. You could also try securing the cord to the floor with duct tape. Lack of regular cleaning may result in the pump becoming clogged with pet hair and food debris. The pump must be cleaned every 24 weeks to ensure proper function. There may be a faceplate cover over the impeller that can be pulled up with a coin or fingernail. Wash the impeller in soapy water, removing hair and other gunk that has collected around it. A small toothbrush might work too, or anything that can reach all the way inside the cavity. Hard water will cause calcium deposits to build up in the pump's cavity, blocking the impeller from spinning. If there is evidence of hard water buildup inside the pump, try adding plain white vinegar inside the pump's cavity without the impeller and allow it to soak for 10-15 minutes. Clean all fountain parts in soap and water before reassembling the fountain. If your pet is prone to chewing, visit your local hardware store and purchase a conduit cover to protect the cord. If the pump has been in regular use for several years, it may be old and need to be replaced. The fountain parts and pump are not UL approved for outdoor use. Using the fountain outside can damage the pump. If you have used your fountain outside, the pump may need to be replaced. To prevent this, always keep your fountain water above the fill line. You can also change the foam filter. This can cause the pump to overheat and stop functioning. When refilling the bowl, make sure to add water before turning the fountain on. Try switching to a top with one fewer spout opening. The charcoal filter is made of organic coconut shells. Rinse the filter in cold water before placing it in the fountain to prevent this.

Some filters may shed more charcoal than others due to differing consistency of charcoal in each batch of filters, so don't be surprised if some filters leave behind more charcoal dust than others. Over time, debris gets stuck in the outer fabric of the filter, making it more difficult for the water to pass through it. The inner part of the filter contains granulated carbon with hundreds or thousands of microscopic holes, which bind to impurities in the water that cause bad tastes and smells. This binding prevents impurities from returning to the water. Eventually, the holes become clogged and can no longer remove impurities. Fountains are top-rack dishwasher safe except for the pump. They are safe to use with your pets drinking water. The organic charcoal used in the filters is made of coconut shells. We're committed to giving you expert advice to ensure you always receive the very best. Please try again later or please contact Customer Care. Would you like to visit our US site? To unplug, grasp the plug, not the cord. Return appliance to the nearest authorized service facility for examination, repair, or electrical or mechanical adjustment. Never yank a cord to remove from the outlet. Fig. 1 It fits in the well diagonally. Figs. 2 A and B. The bottom of the filter is narrower than the top. If placing on carpet or wood floor, the use of a The plug will only fit into a polarized outlet. Do The notches are a passthrough for the cord. They are not for holding the The cord should be passed For quietest A gentle hum during normal operation is to Replace filters more frequently when using the fountain for dogs. Do not wash with Their use is not required for normal operation. Clean fountain and the In between, IMPORTANT The motor must be cleaned regularly or the If you find that difficult, you can push it out from the Fig. 4 A Remove any hair tangled around it and wash it with the Fig. 4 B Rinse well and replace the impeller after Fig. 5 The motor goes in at a right angle to the bowl, Fig.

<http://www.diamondsinthemaking.com/content/e-cafe-pro-manual>

6 The housing will click into place when the tabs on There is an Fig. 8. Fig. 9 This is also an excellent way to disinfect the fountain. You must be sure to rinse The best way to rinse out the If you have "hard water" you may start to see white mineral deposits on or down To avoid having to replace the motor After beginning operation of your Fountain, simply allow your pet to adjust at his or her own pace. Some pets take several days or longer to begin use. Your pet may prefer that the Fountain be placed away from their normal feeding For cats, another idea is to place it up on a counter Add ice cubes to the bowl for refreshing, ice cold running water! If you are concerned about the power cord,

purchase a cord conduit a hard plastic protector at any hardware store. Do not attempt repairs on the motor. Close supervision is necessary when the plug of this device gets wet. Do not attempt to unplug. Always unplug any appliance when to avoid the possibility of the plug or fountain. Examine this appliance after installation. It should not be plugged in if do not operate any appliance if it. If an extension cord is necessary, do not use appliance for other than do not install or store appliance. The electrical use of this appliance is if your cat shows signs of an allergic reaction to the plastic, please if defective, Veterinary Ventures, Inc. P.O. Box 19717. Reno, NV 89511. This warranty does not cover damage from accident, misuse or abuse. It also specifically excludes incidental or consequential damages as Cube YLJP18. Kello 2 asennossa virtaus on suurimmillaan. 8 Lisaa vettä maljaan tarpeen mukaan. Liitä moottori maljaan painamalla moottorin kierteet maljan reian läpi. Moottori menee maljaan oikeassa kulmassa, katso kuvia 6a ja 6b. Muista käyttää suojaavaa pintaa, kuten pyyhettä, tai laita matto suojaamaan lattiasi lemmikkisi aiheuttamilta roiskeilta ja vesipisaroilta. 7 Laita suodatin paikalleen ja täytä kotelo sekä malja vedellä.

Käynnistettyäsi suihkulahteesi anna lemmikkisi tottua siihen omalla tahdillaan. När vredet står på kl 10 är flödet som lägst. När vredet står på kl 2 är flödet som störst. 8 Fyll på vatten i skålen efter behov. Sätt tillbaka motorn genom att trycka in motorns kablar genom hålet i skålen. Motorn ska sättas in i rätt vinkel mot skålen, se Figur 6a och 6b. Se till att använda ett skyddande underlag, t.ex. en handduk eller liten matta, för att skydda golvet från stänk och droppande från ditt djur. 7 Sätt tillbaka filtret och fyll höljet och skålen med vatten. När du startat fontänen kan du bara låta ditt djur vanja sig vid den i sin egen takt. Klockan 10 positionen ger en svag stråle och klockan 2 positionen ger den kraftigaste strålen. 8 Fyll på vatten efter behov. Sätt tillbaka motoren och skyv gjenge på motoren genom hullet i skålen. Motoren ska skyvas in med en höyrevinkel i förhållande till skålen, se Figur 6a och 6b. Pass på att använda en beskyttande överflaten, slik som en handduk eller matte, för att beskytte gulvene dine fra sprut eller drypp fra kjledyrene dine. 7 Sätt tillbaka filteret og fyll huset og skålen med vann. Indstil til svak vandstrøm ved klokken 10 og sterk vandstrøm ved klokken 2. 8 Påfyll vand efter behov. Sett motoren fast igen ved å trkke motorens ledninger igennem hullet i skålen. Sørg for at bruge en beskyttende overflade, sasom et handklode eller en matte for at beskytte dine gulve imod vandsprojt eller dryp fra dit kledyr. 7 Genmonter filteret og fyld huset og skålen op med vand. When the knob is in the 10 o'clock position, flow is at its lowest. When the knob is in the 2 o'clock position, flow is at its highest. 8 Add water to the bowl as needed. Reattach the motor by pushing the threads of the motor through the hole in the bowl. Make sure to use a protective surface, such as a towel or place mat, to protect your floors from splashing or dripping from your pet. 7 Replace the filter and fill the housing and bowl with water.

After beginning operation of your fountain, simply allow your pet to adjust at his or her own pace. Water Capacity PWW0013708, Grey Sep 25 Oct 29 Our payment security system encrypts your information during transmission. We don't share your credit card details with thirdparty sellers, and we don't sell your information to others. To hide it, choose Ship in Amazon packaging at checkout. To hide it, choose Ship in Amazon packaging at checkout. Used Very Good Something we hope you'll especially enjoy FBA items qualify for FREE Shipping and Amazon Prime. Learn more about the program. Please try again. Please try again. In order to navigate out of this carousel please use your heading shortcut key to navigate to the next or previous heading. Register a free business account Please try your search again later. The circulating water stream encourages your pet to drink more. Let us help keep your pet healthy and hydrated so you and your pet can live happy together. The constant water circulation prevents bacteria growth, while the filters remove bad tastes and odors. Set your pet's feeding schedule or give some snacks during the day through the smartphone app-enabled feeder. The activated carbon filter removes bad tastes and odors, while the free falling stream of water entices your pet to drink more. The built-in reservoir increases capacity and makes refills easy. The snap on reservoir lid and rubber feet on the bottom of the fountain prevent sliding

and tipping. Included in the Box PetSafe Drinkwell Platinum Pet Fountain Carbon Filter Fountain Pump with Adaptor Instruction Manual Product Dimensions Water Capacity 168 oz. Fountain Assembled 15.75 in. L x 10.5 in. W x 10 in. H Power Cord Length Approximately 5.5 ft. Frequently Asked Questions Q Can I use this drinking fountain outside. A No, this pet water fountain is designed for indoor use only. Q How often should I clean my pump.

A You should disassemble and clean your pump every 2-4 weeks to help keep your fountain running optimally. I love this fountain. D. Cavanagh Videos for this product 424 Click to play video Customer Review My cats love it, I love it. Will purchase again. Cats Cuddles Videos for related products 325 Click to play video The 5 Best Pet Fountains BestReviews Videos for related products 324 Click to play video The 5 Best Pet Fountains BestReviews Videos for related products 810 Click to play video Cat Favorites 9 Cool Things Cats Want Today. I love this fountain. See full review D. Cavanagh Onsite Associates Program To calculate the overall star rating and percentage breakdown by star, we don't use a simple average. Instead, our system considers things like how recent a review is and if the reviewer bought the item on Amazon. It also analyzes reviews to verify trustworthiness. Please try again later. Jennifer L. Manchester 5.0 out of 5 stars Now, almost 2 years later, we still have no trouble, like some reviewers have had. I believe the key to this success is the cleaning of the fountain AND the pump. Once per week we disassemble the ENTIRE fountain. All components get cleaned with a mild liquid dish soap and warm water. Whats key here is the full disassembly. Note in the photos section I have shown the fountain taken apart. You will see that one piece came OFF of the front of the pump. This allows us to clean the gunk that gets built up inside the fountain. This is very easy. Of course, the pump should be unplugged prior to cleaning. Then remove the front, and place pump in a cup of warm water with a tsp of powder dish detergent. While submerged, we plug the pump in. This circulates the water and detergent to clean the spinning mechanism inside. See in another photo the debris floating in the water. That is the gunk that builds up. So if you are experiencing pump failure, this may be the reason.

If your pump is so bad the spinning mechanism does not spin, simply soak the pump in the water and detergent for a couple of hours, then flush well with clean water and try again. IMPORTANT When you put the front cover back onto the pump, if it does not close all the way, do NOT force it. The flow control valve MUST line up. So turn your flow control slightly and try again. Continue to make slight turns and try again until it snaps EASILY back together. When done regularly, this weekly cleaning does not take us much time at all and is completely worth the effort. Other than this cleaning, our fountain has required no maintenance. We change the filter one or twice per month, as needed. After cleaning, we fill the base with water AND fill the reservoir. It is enough water to last well over that week. This fountain gets daily use by two cats, so you may through more water with dogs or more cats. I hope this review will help you love your Pet Fountain! There just seemed to be so many factors to consider. Well I and my pets couldnt be happier with this choice. I bought it primarily for my diabetic 10 year old cat who has had 3 recurrent, painful bouts of cystitis. Animals drink more water if its fresh and oxygenated so I hoped this would help. I have another cat that I knew would play in it, climb on it, and knock it over if possible. So weight was a consideration, as was flow so it would be like the sink stream. My 3 cats and small dog all love it and are drinking much more than they had been. My daughters puppy stays with me during the day sometimes and the first thing he does is run to the fountain when he comes in the door. The cat that demanded the sink be turned on no longer does that and enjoys playing in the water stream in the fountain. The steam is adjustable and I turned it to the lowest setting to simulate the sink. I read that others felt it was hard to clean.

I bought a cheap bottle brush at Walmart and I cleaned it for the first time today and it took about 5 minutes. The prefilter really helps with fur and dirt not getting to the motor. The fountain is almost silent when running. The motor has suction cups on the bottom so it doesnt move and vibrate. The water stream falls on a piece made to prevent it falling directly onto the water in the bowl so there is

no sound from that. There is almost no scum buildup as there is in a regular bowl. Finally, I considered weight because I knew one cat would climb on it and it is heavy and stable enough to prevent tipping, especially with a full tank. The clear reservoir tank in the back allows easy monitoring of the water level. This model holds a lot of water, way more than I thought we would possibly need. I was wrong. They love it so much that they drink more than I expected. I would recommend this to everyone. It hasn't created a mess in my house, and with regular cleaning and refilling could be set and forget for a few days. The real issue with this fountain is how frustrating it is to clean. It's almost as if the engineers who put this together don't have pets themselves. After more than a few days, and I start to see grit on the bottom of the fountain. At this point, if I don't dump the water and scrub the entire thing out, the grit progresses to a whitish orangish blobby sludgy block that gets in every crevice in this thing. Remember me mentioning the engineers earlier. Here's where they come in this fountain has impossible to clean crevices. You will need several types of brushes to clean this, and some pipe cleaners wouldn't hurt either. The bowl itself looks great, but you see the thing the water splashes on. Look at the tiny space behind and beside it. You will need to clean this somehow. The water tower with the filter. You need a thin bottle brush for this. It's a tiny space, and you need to clean it somehow. After you clean that tube, look at where the filter rests.

Those long thin slots that hold it. You'll need to clean those. There is no brush long enough, and you'll end up with a scotchbrite pad on the end of a butterknife trying to get the gunk out. So the whole reason you want this cool fountain is because the waterfall circulation, right? Me too. And your pets, they'll love it. You will not, because you will see all the sludge that builds up inside the pump itself. Like me, you may try pumping bleach water through it outside the fountain to clean it out and kill the sludge. The sludge smiles at you and laughs though, because this isn't going to work. I will tell you the secret here though. The pump comes apart. Yes, it's true. I'm pretty sure this isn't by design, but it works and allows you inside the very center of sludge's lair. Look at the pump. See the hole it pumps water from. There's a seam that runs all the way around the pump right near that outlet. Grab the tube that controls the water flow and pull straight out. It will require a little more force than you are comfortable with, but it will pop off. Once you slay the beast inside the pump, and the rest is clean you're good to go. But seriously, who designed this that has tiny doll-like hands that can reach in those crevices. When I think of some of the design decisions that were made here, it's a bit mind-boggling. I bought it for my Maine Coon whom I'm trying to encourage to drink more water, crystals, without running up the water bill by leaving a tap on. She LOVES THIS. You can adjust the speed of flow and with that, the trickle noises are adjusted, something she needs to draw her to water alongside the water sparkles. It's very quiet. I will be purchasing a big bucket type thing to put it in as she loves to play with water and she also likes to clean her paws after she's used the litter tray. She sits by this fountain like she used to sit by the koi pond I built for her. Honestly it's brilliant.

I'm happy with the speed of arrival and the way it's packaged and ease of putting together. First one lasted 3 years. They used it as soon as I set it up, and they drink from it whenever they want. It has stopped them being desperate to drink from the taps in fact they don't do that anymore. The motor is quietish. The trickle rate is good and the capacity is certainly enough for two cats. In order to navigate out of this carousel please use your heading shortcut key to navigate to the next or previous heading. Water Capacity PWW0013708, GreyWater Capacity. To reduce the risk of injury, close supervision is. To unplug, grasp the plug, not the cord. 7 Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been dropped or damaged in any manner. Call customer service immediately for further instructions. 8 For a portable appliance To reduce the risk of electrical shock, do not place or store appliance where it can fall or be pulled into a tub or sink. 9 Always unplug any appliance when not in use, before putting on or taking off parts, and before cleaning. Never pull on the cord to remove the adaptor from the wall outlet. 10 Do not use appliance for other than intended use. SAVE THESE INSTRUCTIONS 14001366 Ceramic Lotus Pet

Fountain Operating Guide U.S. Patents No. 5,799,609 and 5,842,437 Thank you for choosing the PetSafe brand. You and your pet deserve a companionship that includes memorable moments and a shared understanding together. Our products and training tools promote a lifestyle of protection, teaching and love; essentials that influence memories for a lifetime. Make sure the nut on the bottom of the bowl is fully tightened and secure. See Fig. 2 Fig. 1 Fig. 24 Remove the housing by lifting straight up. Several parts will already be in place, including the foam filter, pump, intake tube, cord passthru tube, gasket and the tube connector. See Fig.

3a Make sure the electrical cord is secured in place by the clip on the tube connector. See Fig. 3b Fig. 3a Fig. 3b 5 Replace the housing by aligning the large gap at the bottom of the housing with the raised bump on the bottom of the main bowl. The gap in the housing is shown in Fig. 4a next page and the raised bump is circled in Fig. 4b next page. The housing should rest flat and stable on the bottom of the bowl. If the housing is slightly raised up or wobbles at all, it is placed incorrectly, remove and replace the housing as instructed above until it rests flat. 3 Fig. 4a Fig. 4b 6 With the housing in place, affix the housing cap by aligning the arrow on the cap with the picture of a lock on the housing See Fig. 5. With these two items aligned, press down on the cap while simultaneously turning it to the right, this will secure the cap. Fig. 5 Fig. 6 7 Place the Oring over the housing. See Fig. 6 Next, slide the upper dish onto the housing. Rotate the upper dish until you are happy with how the spouts line up with the bottom bowl. 8 Adjust the flow of water by turning the housing cap in between the two arrows marked on the side of the housing. If placing on carpet, tile or wood flooring, always use a protective mat or other durable, water resistant surface to help protect your floor from splashing or dripping. 10 Fill the fountain with water by pouring water directly into the bottom bowl and upper dish. Fill the fountain with water to the MAX Fill Line. 11 Before you plug the fountain in, make sure the cord and your hands are dry. Plug the fountain into an electrical outlet. 12 Add water to the fountain as needed. Empty all of the water out of the fountain. Fig. 7 Fig. 8 4 With the housing removed and the fountain completely empty, turn the bowl over to loosen and remove the nut on the bottom of the bowl. See Fig. 9 5 Next, remove the intake tube from the pump by lifting straight up. Grab the Cord PassThru Tube and lift up to expose the hole in the bottom of the bowl.

Pull the electrical cord through the opening until completely removed. 6 Once the electrical cord has been removed from the bowl, continue pulling the cord through the Cord PassThru Tube. See Fig. 10 Fig. 9 Fig. 10 5 7 With the cord completely removed, the pump and filter should now be separated from the rest of the internal parts. With all the parts completely disassembled, you will have 2 ceramic bowls, 6 plastic parts, an Oring, a rubber gasket, foam filter and pump. 8 Clean all the fountain parts except the foam filter with warm water and soap. You can also put the fountain in the top rack of the dishwasher. Never place the pump in the dishwasher, only the plastic and ceramic pieces. If possible, it is recommended that you turn down the heat of the water inside the dishwasher. See the "Pump Maintenance" section of this manual for detailed instructions on how to clean your pump. **REPLACING THE FILTER FILTERS CHANGE EVERY 2 to 4 WEEKS** 1 Filters should be changed every two to four weeks. Replace filters more frequently when using the fountain for multiple pets or pets that produce a lot of saliva. 2 Filters are an added feature of the fountain. Their use is not required for normal operation. 3 Filters may be rinsed out when the fountain is cleaned. Never wash the filter with soapy water, as the soap residue will seep into the filter and cannot be removed. Only rinse the filter with water. 4 For replacement filters, visit a local pet store or call 8663222530. Order online by visiting [www.petfountain.com](http://www.petfountain.com) and using our retailer locator. **6 PUMP MAINTENANCE** Cleaning the pump is essential to the longevity of the fountain as well as the cleanliness of the water. Clean the pump every 2 weeks. **Stator Intake Plate Pump Impeller** 1 Once the pump is out of the fountain, with your thumb and forefinger, gently squeeze on either side of the intake plate and pull off. Use a cotton swab or bottle brush to get into the pump's cavity and remove any buildup. See Fig.

13 For added disinfecting and hard water removal, clean the pump with white vinegar.<sup>5</sup> Once the parts are clean, you can reassemble the pump for use.

### REASSEMBLY OF YOUR FOUNTAIN

- 1 Replace the gasket on the Cord PassThru Tube. See Fig. 14
- 2 With the gasket attached, place the Cord PassThru Tube into the opening in the bottom of the bowl. Make sure the curve of the tube is facing towards the center of the bowl. Move the Tube Connector up the shaft of the Cord PassThru Tube slightly to make room for the Intake Tube. See Fig. 18
- 3 With both tubes in place, slide the Tube Connector back down the shaft so that it encompasses both tubes. Next, remove any extra slack from the electrical cord by pulling the cord out the bottom of the bowl. Clip the cord in place as shown in Fig. 19.
- 4 Fig. 18 Fig. 19
- 5 Next, replace the housing by aligning the large gap at the bottom of the housing with the raised bump on the bottom of the main bowl. Once in place, replace the O-ring and the upper dish. If placing on carpet, tile or wood flooring, always use a protective mat or other durable, water resistant surface to help protect your floor from splashing or dripping.
- 6 Fill the fountain with water. Before you plug the fountain in, make sure the cord and your hands are dry. We recommend using a solution that is 10% bleach and 90% water. Pour some of the bleach solution down into the pump's cavity as well. You must be sure to rinse all the parts very thoroughly to remove all the chlorine. The best way to rinse out the pump's cavity is to hold it under a weak stream of warm water. This is also an excellent way to disinfect the fountain. If you have "hard water" where you live, you may start to see white mineral deposits on or down inside the pump. This may eventually prevent the impeller from turning properly. Some pets may take several days or longer to begin use. Your pet may prefer that the fountain be placed away from their normal feeding area.

<https://www.interactivelearnings.com/forum/selenium-using-c/topic/19740/e-cigarette-user-manual>